ePED DISPLAY DOOR TERMINAL & SURFACE BACK BOX

INSTRUCTIONS

1. Select a suitable location for the ePED Display Door Terminal and Surface Back Box
2. The surface should be flat in the area of the fixings and the material suitable to hold the weight.
3. Produce wire/cable hole in the area.
4. Fit the ePED Surface Back Box to the area in direction arrow 1. Use appropriate 4 No. fixing screws through clearance holes A. Fixing screws not supplied.
5. Feed wire/cable through clearance hole C and connect to the ePED Display Door Terminal.
6. Fit the ePED Display Door Terminal the ePED Surface Back Box in direction arrow 2. Use 4 No. fixing screws supplied with the ePED Display Door Terminal to threaded holes B.